




**BMS NOW HAVE THE PITO15 ASSEMBLY IN
STOCK BMS-55000461**



**ALSO NEW INTO STOCK THE PITO15
HYDRAULIC CYLINDER BMS-23777028**





COMPONENTS FOR DP1500i/DP1100i/D650i

BMS-04976998 - Shaft

BMS-08554608 – Bushing

BMS-09020548 – Shaft

BMS-13391238 – Bushing

BMS-13392408 – Bearing Bushing

BMS-13394418 – Bearing Bushing

BMS-13394678 – Bearing Bushing

BMS-13791308 – Bracket

BMS-13842538 - Bearing Bushing

BMS-13848058 – Bearing Bushing

BMS-20774308 – Nut

BMS-20782438 – Locking Screw

BMS-20782568 – Adjusting Screw

BMS-20910448 – Slipper Pad

BMS-23208798 – Shim





BMS-23220778 – Bushing

BMS-23212108 – Flange

BMS-23291108 – Bearing Bushing

BMS-23328628 – Bearing Bushing

BMS-23328758 – Bearing Bushing

BMS-23333588 – Shaft

BMS-23337648 – Bushing Bearing

BMS-23338098 – Flange

BMS-23349158 – Washer

BMS-23469408 – Shim

BMS-23486148 – Pin

BMS-23486278 – Pin

BMS-23493018 – Sprocket

BMS-23494158 – Sprocket

BMS-23501698 – Slide Piece

BMS-23503238 – Sprocket

BMS-23575118 – Lever





BMS-23611008 – Slipper Pad

BMS-23611128 – Slipper Pad

BMS-23611798 – Pin Assembly

BMS-23507148 – Sprocket

BMS-23564468 – Shaft

BMS-23611948 – Pin Assembly

BMS-23612138 – Pin Assembly

BMS-23618478 – Jaw

BMS-23618508 – Jaw

BMS-23635378 – Slipper Pad

BMS-23756218 – Pin Assembly

BMS-23756348 – Flange

BMS-23761048 – Hose Roller

BMS-23764228 – Reel Hose

BMS-23776708 – Jaw

BMS-25858048 – Wiper

BMS-26337627 – Slipper Pad





BMS-26380298 – Bushing

BMS-26474208 – Bushing Bearing

BMS-26516428 – Bushing Bearing

BMS-27377028 – Cylinder

BMS-32227848 – Idler Wheel

BMS-33001698 – Slide Piece

BMS-33059858 - Wheel Idler

BMS-33161258 – Locking Pin

BMS-42205620 – Circlip

BMS-42206630 – Circlip

BMS-44687520 – Pan Head Screw

BMS-47669448 – Ring

BMS-52216670 – O-Ring

BMS-55003492 – Guide

BMS-55004475 – Cylinder

BMS-55004569 – Cylinder

BMS-55007736 – Cylinder





BMS-55036002 – Swing Piece

BMS-55036003 – Plate Divider

BMS-55050626 – Bracket

BMS-55051198 – Idler Wheel

BMS-55051837 – Guide

BMS-55051963 – Ring

BMS-55052073 – Hydraulic Cylinder

BMS-55052106 – Cylinder

BMS-55052858 – Ring

BMS-55052860 – Housing Bearing

BMS-55053110 – Shaft

BMS-55053330 – Shaft

BMS-55054108 – Body

BMS-55059389 – Bushing

BMS-55067563 – Hydraulic Cylinder

BMS-55071133 - Bearing Bushing

BMS-55071134 – Pin





BMS-55076116 – Pin Assembly

BMS-55076319 – Shaft

BMS-55076372 – Pin Assembly

BMS-55076379 – Pin

BMS-55076458 – Ring

BMS-56169508 – Bushing

BMS-80006579 – Spring Pin

BMS-80008749 – Spring Pin

BMS-80101009 – Wiper

BMS-80264669 – Spring Pin

BMS-81360009 – Bushing

BMS-81503779 – Flange Bushing

BMS-87252589 – Lock Nut

BMS-88343349 – Hydraulic Motor

BMS-88722609 – Plain Bush Dry

BMS-55000434 – Front Plate Assy

BMS-55000438 – Rear Plate Assy





BMS-55000310 – Arm Assembly

BMS-05231878 - Jaw (right)

BMS-05231748 – Jaw (left)

BMS-55000442 – Shaft

BMS-86910619 – Roll Pin

BMS-55057312 – Seal Kit

BMS-55167987 – Motor Assembly

BMS-55040711 – Lock Rubber

BMS-55065365 – Lock Rubber

BMS-13488718 – Suction Cup

BMS-55057616 – Plain Bearing

BMS-55055986 – Pipe Assembly

BMS-55056005 – Pipe Assembly

BMS-23617617 - T60 Jaw (right)

BMS-T60 Jaw (left)

BMS-30834849 – Compressor (Air End)

BMS-55158398 – Transmitter





BMS-80698209 - Check Valve

BMS-55171802 – Seal

BMS-BG01264705 - Seal Kit

BMS-86766699 - Seal Kit

BMS-55079260 - Seal Kit

BMS-88231419 - Seal Kit

BMS-81959369 - Seal Kit

BMS-81972669 - Seal Kit

BMS-55074935 - Seal Kit

BMS-88639019 - Seal Kit

BMS-81959269 - Seal Kit

BMS-55154230 - Seal Kit

BMS-55005392 - Air Cylinder

BMS-55073166 - Pressure Reducing Valve

BMS-55154240 – Spring

BMS-55181177 – Coil

BMS-55154041 - Electronic Pilot Module





BMS-55163293 – Spring

BMS-55084490 – Bracket

BMS-81096139 - Seal Kit

BMS-88658909 - Overcentre Valve

BMS-55153141 - Overcentre Valve

BMS-03403598 - Sight Glass

BMS-88761319 - Directional Valve 3/2

BMS-88761299 - Repair Kit

BMS-88110729 - 3/2 Hydr Cartridge Valve

BMS-BG01560313 – Valve

BMS-55027620 - Joined Piece

BMS-88727779/BG01122638 - Unloader Valve

BMS-55024151 - Seal Kit

BMS-BG00568286 - Seal Kit

BMS-55022977 - Repair Kit

BMS-55042005 - Seal Kit

BMS-55016610 - Repair Kit





BMS-55024136 – Diaphragm

BMS-55032339 – Diaphragm

BMS-80765059/BG00568289 - Diaphragm Flat

BMS-55079198 - Pre-Wired Plug Cable

BMS-55078884 - Pre-Wired Plug Cable

BMS-55181935 - Pressure Transmitter

BMS-55156667 - Wiring Harness Assembly

BMS-80687019 - Pressure Switch

BMS-80631029 – Bulb

BMS-85627379 – Light

BMS-88726229 - Sensor Cable

BMS-55050052 - Wiring Harness

BMS-88761039 – Coil

BMS-55024054 – Coil

BMS-55022978 – Solenoid

BMS-55030723 – Holder

BMS-55018543 - Potentiometer Assy





BMS-09412168 - Potentiometer Ass

BMS-55047278 - Contact Block

BMS-55047276 - Contact Block

BMS-55047565 – Adapter

BMS-55054623 - Potentiometer

BMS-55163818 - Switch Foot Pedal

BMS-CP000955/BG01082307 - Safety Relay

BMS-55025479 – Thermostat

BMS-55047550 - Pilot Light Green

BMS-55047577 - Led Light

BMS-04730854 - Adjusting Knob

BMS-55182270 - Starter Unit

BMS-55182273 - Control System

BMS-88640479 - Push Button

BMS-85675399 – Bulb

BMS-88483369 - Circuit Breaker

BMS-55077705 - Circuit Breaker





BMS-55165235 - Circuit Breaker

BMS-55077702 - Circuit Breaker

BMS-55055808 - Circuit Breaker

BMS-08003325 – Relay

BMS-55163844 – Switch

BMS-55163849 – Switch

BMS-5509339 – Relay

BMS-55163846 – Switch

BMS-08900353 - Socket Relay

BMS-88657749 – Relay

BMS-55032288 – Terminator

BMS-88368339 - Relay Base

BMS-55087919 – Relay

BMS-55084232 – Distributor

BMS-04907628 - Pin

BMS-55011532 - Sun Gear

BMS-55000669 - Special Tool Kit





BMS-23706158 - Hose Support

BMS-25821008 - Rotation Jaw

BMS-55084954 – Pipe

BMS-BG00248946 - Pipe

BMS-55045005 – Sensor

BMS-55007741 - Hydraulic Cylinder

BMS-55052106 - Cylinder

BMS-16239508 – Cover

BMS-55077298 - Pin

BMS-55029448 - Coupling

BMS-88212629 - Cable Support

BMS-87252589 - Lock Nut

BMS-AF20010023 – Circlip

BMS-AF00600169 - Screw Socket Head

BMS-81503779 - Flange Bushing

BMS-85069889 - Bearing

BMS-55167965 – Ring





BMS-81386399 - Bushing

BMS-81384119 - Bushing

BMS-56169508 - Bushing

BMS-23610938 - Slide Plate

BMS-55003492 – Guide

BMS-13390918 - Bearing Bushing

BMS-55051963 – Ring

BMS-08554588 – Sleeve

BMS-81500209 – Spacer

BMS-23220778 - Bushing

BMS-08584288 – Sleeve

BMS-55168783 - Safety Limit Switch

BMS-85043339 - Oil Level Indicator

BMS-88214089 – Wire

BMS-55172031 - Joystick Accessory

BMS-88212509 - Cable Grip

BMS-55083562 - Adapter Piece





BMS-55083087 - Valve Block

BMS-88243469 - Screw Plug

BMS-55080134 – Sensor

BMS-55025694 - Repair Kit

BMS-55073165 - Pressure Regulating Valve

BMS-88509309 - Cartridge Directional Valve

BMS-BG00222262 - Pressure Reducing Valve

BMS-55075806 - Prop Press Relief Valve

BMS-85824369 - Non-Return Valve

BMS-505812 - Valve Press Reducing Prop

BMS-55003291 - Lube Unit

BMS-55167577 – Shim

BMS-20774307 - Nut

BMS-20774308 - Nut

BMS-55011704 - Disc Spring

BMS-23354008 – Plate

BMS-20910578 – Plate





BMS-BG00932314 - Repair Kit

BMS-55011218 - Control Valve

BMS-55024118/BG01560313 - Valve

BMS-86663119 - Grease Nipple

BMS-23616458 – Nozzle

BMS-86663249 - Gasket

BMS-88537409 - Fill Cap

BMS-55076047 - Vibration Damper

BMS-55058564 – Fitting

BMS-55163698 - Plug-In Holder

BMS-56043800 - Water Pump

BMS-55168370 – Latch

BMS-55074091 - Rubber Bushing

BMS-55163788 – Nozzle

BMS-55161126 – Latch

BMS-04790110 - Hose Clamp

BMS-55075910 - Hose Clamp





BMS-80685799 - Hose Clamp

BMS-85342359 - Hose Clamp

BMS-85194549 - Hose Clamp

BMS-BG00211891 - Pressure Pipe

BMS-09260298 – Diaphragm

BMS-AF25010520 - O-Ring

BMS-15414748 – Flange

BMS-23338098 – Flange

BMS-81862479 - Mud Separator

BMS-20797408 - Bushing

BMS-13390078 - Bushing

BMS-15188338 - Gasket

BMS-15191708 - Gasket

BMS-15241788 - Gasket

BMS-55199508 - Gasket

BMS-55199526 – Gasket

BMS-55000211 - Pipe Clamp





BMS-55000212 - Pipe Clamp

BMS-55000214 - Pipe Clamp

BMS-55000209 - Pipe Clamp

BMS-55053110 – Shaft

BMS-55012600 - Retainer Screw

BMS-55187159 – Screw

BMS-55023917 - Pressure Spring

BMS-88321789 – Dryer

BMS-80101009 – Wiper

BMS-88722729 - Bearing Shell

BMS-55000445 - Limit Plate

BMS-23347958 – Pipe

BMS-55000611 – Pipe

BMS-13394548 - Bushing

BMS-88544789 - U Seal

BMS-23328888 - Bearing Bushing

BMS-61806709 – Lock





BMS-13394828 - Bushing

BMS-08584028 - Sprocket Wheel

BMS-55083594 – Shaft

BMS-09019198 – Gear

BMS-09019068 – Gear

BMS-34483978 - Bearing Bushing

BMS-55083592 – Shaft

BMS-13416308 - Key

BMS-55182265 – Cooler

BMS-55170939 - Rubber Sheet

BMS-55071134 - Pin

BMS-26378108 - Taper Pin

BMS- 23635378 – Guide

BMS-09018878 – Shaft

BMS-23200698 – Shim

BMS-81500189 - Connecting Pin

BMS-55000443 – Shaft





BMS-55069192 – Pipe

BMS-13593968 - Rotation Roller

BMS-55076319 – Shaft

BMS-CQ41126-11 – Bushing

BMS-23210468 - Lock Washer

BMS-23511528 – Pin

BMS-55050891 - Wear Plate

BMS-81499509 - Shock Absorber

BMS-88718509 - Seal Kit

BMS-86930549 - Seal Kit

BMS-85670069 - Seal Kit

BMS-55064767 - Seal Kit

BMS-55087858 - Seal Kit

BMS-85069909 - Seal Kit

BMS-88399339 - Seal Kit

BMS-55039115 - Seal Kit

BMS-86817009 - Seal Kit





BMS-55073895 - Seal Kit

BMS-23575118 – Lever

BMS-55054108 – Body

BMS-55161124 - Wiper Arm

BMS-16313908 - Bushing

BMS-15250138 - Opener

BMS-20841018 - Adjusting Piece

BMS-55077003 - Base Plate

BMS-55034796 - Coupling

BMS-55000533 - Wire Rope

BMS-55043531 - Wire Rope

BMS-55000531 - Wire Rope

BMS-88610369 – Handle

BMS-55070260 – Decal

BMS-55070338 – Decal

BMS-BG00837519 - Valve Block

BMS-15245028 - Gasket





BMS-81051209 - Split Pin

BMS-BG00326356 - Overcentre Valve

BMS-81816349 - Pressure Gauge

BMS-03600148 - Spring Pin Coiled

BMS-45368998 – Bushing

BMS-55000321 – Bushing

BMS-AF00101439 – Screw

BMS-55030221 - Rod End Kit

BMS-86727309 - Hex Bolt

BMS-14910193 - Head Bolt

BMS-55058253SX - Hydraulic Pump Axial Piston

BMS-55042004SX - Piston Pump

BMS-BG01441330 - Rubber Hose

BMS-55170789 - Air Conditioner

BMS-55074636 - Radiator Core

BMS-55196876 - Wheel Assembly

BMS-BG01207257 – Sprocket





BMS-BG01207257 – Sprocket

BMS-55016352 - Hydraulic Motor

BMS-09019068 – Gear

BMS-08583838 - Shaft Pin

BMS-08554608 – Sleeve

BMS-23456728 – Pin

BMS-23861203SX - Hydraulic Cylinder (boom swing)

BMS-55071031SX - Hydraulic Cylinder (double acting)

BMS-55056623 - Suction Head

CONTACT FOR LATEST PRICING

info@breakoutmechanical.au

sam@breakoutmechanical.au

scottj@breakoutmechanical.au

1300 193 411

